

Over 50 years

The longest established cleanroom company in the UK



BASSAIRE

IS CLEAN AIR

Softwall cleanrooms

Mobile laminar flow enclosures

Softwall Cleanrooms are an economical and versatile solution for providing a localised clean environment without having to modify existing facilities. Constructed from high quality carbon steel powder coated or stainless steel, with PVC curtain or clear acrylic infill panels. Available as static or mobile versions.

Softwall cleanrooms can be created to provide clean conditions ranging from ISO Class 1 to Class 8 cleanliness.

Specification

- Dimensions: Units are built to suit any specific requirement
- Air Flow: To any configuration required
- Structure (main frame): High quality carbon steel powder coated white or stainless steel
- Structure (sidescreens): Flexible PVC curtain (strip or sheet) or rigid acrylic panels
- Feet: Lockable castors or adjustable levelling feet
- Pre-filter: 92% efficient at 5.0 micron
- HEPA Filter: 99.995% efficient at the MPPS (EN 1822 Class H14)
- Electrical Supply: 230-240V 50/60Hz single phase. All units are PAT tested and have individual fused protection
- Fan(s): Double inlet, centrifugal, super silent and thermally protected
- Lighting: Lux level as required
- Controls: options include; UCP, Minihelic Pressure Gauge, Digital Airflow Meter & Visible Alarm (for Fan Failure or Filter Failure)



Optional features

Options include:

- Full installation services available
- HEPA filter fitted as standard. ULPA filter available on request
- Stainless steel mesh filter face for use with stainless steel units
- Auxiliary power outlets (standard or IP65)
- Adaptation to accept ductwork connections
- Static eliminator bar c/w controls
- Gold or UV lighting

Further options are available on request

Other products and services

Bassaire has over fifty years experience in the design, manufacture, installation and maintenance of cleanrooms and clean air products.



cleanrooms



laboratories



clean air products



servicing

ds-softwall-cleanroom-v2

www.bassaire.co.uk

www.bassaire.co.uk | Tel: +44 (0) 1489 885111 | Fax: +44 (0) 1489 885211 | Email: sales@bassaire.co.uk

Bassaire Limited · Duncan Road · Park Gate · Southampton · Hampshire · SO31 1ZS · England

Registered in England: 2107555 · © Bassaire Limited